



Diversey Disposable Wiping System

Pre-wetting Instructions

How to Use Diversey Cleaners and Disinfectants with Disposable Dry Wipes:

Both ready-to-use (RTU) and concentrated cleaners and disinfectants that have been properly diluted, may be used with Disposable Dry Wipes. Use of Diversey cleaners and disinfectants with Disposable Dry Wipes provides customers with the labor savings and convenience of using disposable wipes to clean and disinfect hard nonporous surfaces.

Following are directions on how to use Diversey cleaners and disinfectants with Disposable Dry Wipes:

1. Open the wipe canister / bucket by pulling the large perimeter lid (not by the hinged cap).
2. Calculate the amount of liquid to add to the dry wipes using the estimate of .004 oz per square inch of wipe (estimate 2 quarts for 125 sheets that are 10.5x12). The amount of liquid can vary based upon the absorption of the wipe.
3. If using a concentrated chemical, ensure the cleaner / disinfectant is properly diluted.
4. Add ½ of the calculated liquid cleaner / disinfectant to the bottom of the empty container that is being used for the wipes prior to adding any of the dry wipes to the container.
5. Place the stack / donut of dry wipes into the container being used. Pour the remaining ½ of the liquid over the dry wipes.
6. Allow 5-10 minutes for the solution to be absorbed into the wipes.
7. Label the container so it clear what cleaner / disinfectant is in use. Include the date the wipes were wetted. Generally, the shelf life is 24 hours from when the wipes are pre-wet. If you are using an Improved or Accelerated Hydrogen Peroxide® product with Diversey EasyWipes™ or Dry Wipes, the shelf life is 28 days (when pre-wetted onsite).
8. Refer to the original product label for directions for use and surface contact times.
9. Close the container after each use to prevent loss of cleaning/disinfectant solution and to protect the solution from contamination.



Please contact Customer Technical Service if there are any questions at 1-800-558-2332, Option 5.